

La Spaziale S1 – Cheat Sheet

Chris' Coffee Buyer's Guide



Turn it on: Press and hold the ON/OFF button for three seconds.

Turn it off: Press the ON/OFF button briefly. The ON/STBY light will blink.

Turn boiler on/off: Press and release the BOILER button. This will reset each time you turn the machine off.

For hot water: Press and release the water button; press and release again to stop.

Enter Economy mode: Press and hold the BOILER button for ten seconds to toggle it on and off. This will be remembered when you turn the machine off.

Setting the auto-dosing:

1. Machine must be on. Place a cup under the spout.
2. Press and hold the ON/OFF button for three seconds. Current temperature light will blink.
3. Press and release the one or two cup button. Pump will start.
4. Once the cup is filled to the desired level, press and release the same button a second time.
5. Press and release the ON/OFF button to exit programming.

Changing the temperature in 5C increments (85, 90, 95, 100, ...):

1. Machine must be on.
2. Press and hold the ON/OFF button for three seconds. Current temperature light will blink.
3. Press and release the water tap button; the temperature will move to the next temperature (95, 100, 110, 115, 120, and then back to 85)
4. Press and release the ON/OFF button to exit programming.

Changing the temperature in 1C increments "fine tuning" (+1, +2, +3, 0, -1, -2, -3):

1. Note the current temperature in 5C increments (85, 90, 95, 100, 105, 110, or 120). The machine must be on.
2. Turn the machine off by pressing and releasing the ON/OFF button (ON/STBY light is blinking).
3. Press and hold the two-cup button for three seconds. Two amber lights will be solid. The number of blinking lights to the left of the two amber lights indicates how many degrees are SUBTRACTED from the temperature; the number of blinking lights to the right of the two amber lights indicates how many degrees are ADDED to the temperature.

Examples:

- The 95C light is on before entering fine-tune mode; after step 3, two lights to the right of the two solid amber lights are blinking. The current setting is $95+2 = 97C$.
 - The 90C light is on before entering fine-tune mode; after step 3, two lights to the left of the two solid amber lights are blinking. The current setting is $90+2 = 92C$.
 - The 95C light is on before entering fine-tune mode; after step 3, only the two amber lights are on. The current setting is $95+0 = 95C$.
4. To subtract 1C, press the single cup button; to add 1C, press the BOILER button. If no lights are blinking (only the two amber lights in the center are on), nothing is added to the 5C increment temperature
 5. Press and release the two-cup button to save your changes and exit programming.
 6. Press and hold the ON/OFF button for three seconds to turn the machine back on. If you had the boiler off beforehand, remember to turn it off again by pressing and releasing the BOILER button.

La Spaziale S1 – Cheat Sheet

Chris' Coffee Buyer's Guide

Fine tuning the brew temperature

	Adjustment Lights On							
	85	90	95	100	105	110	120	ECON
-3	●	●	●	●	●	●	●	●
-2	●	●	●	●	●	●	●	●
-1	●	●	●	●	●	●	●	●
0	●	●	●	●	●	●	●	●
+1	●	●	●	●	●	●	●	●
+2	●	●	●	●	●	●	●	●
+3	●	●	●	●	●	●	●	●

Note: The table above is for current versions of the La Spaziale S1. For the machines shipped before February 2004, the blinking fine-tuning lights on the left indicated an increased incremental temperature and lights on the right indicated a decreased incremental temperature. Current shipments operate in the more intuitive direction shown above.

Temperature conversion

<i>Celsius</i>	<i>Fahrenheit</i>
85	185.0
86	186.8
87	188.6
88	190.4
89	192.2
90	194.0
91	195.8
92	197.6
93	199.4
94	201.2
95	203.0
96	204.8
97	206.6
98	208.4
99	210.2